





COMMENT FAIRE DE LA RELECTURE SUR LE WEBSERVICE ?

1 - Je vais sur le webservice de mon NVR avec mon écran et ma souris.
Par défaut l'ip est 192.168.1.65


2 - Je me connecter avec mes identifiants (par défaut "admin/12345").



3 - Je clique sur l'icône encadré en rouge à gauche de mon écran.



4 - Je choisis ma date/l'heure puis ma caméra ensuite cliquez sur aller.



5 - Vous pouvez maintenant naviguer avec la frise chronologique situé en bas .

The screenshot displays a video surveillance software interface. The main window shows a live feed from camera CA20HDf, timestamped 04/08/2022 05:05:40. The feed shows an office interior with a reception desk, a potted plant, and a large window. To the left of the main feed is a sidebar containing a list of cameras: HD732, [1] CA10HDb, [2] CA60HDc, [3] CA20HDf (selected), [4] CA50HDj, [5] CA80HDe, [6] DA330HDc, [7] DA630HDc, [8] DA350HDg, [9] DA450HDh, [10] DA650HDh, and [11] DO410HDd. Below the camera list is a calendar for August 2022, with the 4th highlighted. At the bottom of the sidebar are playback controls, including a time input field set to 09:01:48 and an 'Aller' button. The bottom of the main window features a playback timeline with a blue bar labeled 'CH3' and a time scale from 00 to 08. Playback controls (play, pause, stop, etc.) are located above the timeline.